



TOOL MODEL: MXT 20

PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	FT.LBS.	TORQUE IN KGM	NM	PRESSURE IN BAR
1500	2960	409	4013	104
1600	3158	437	4281	110
1800	3554	492	4818	124
2000	3950	546	5355	138
2200	4346	601	5891	152
2400	4742	656	6428	165
2600	5138	711	6965	179
2800	5534	765	7502	193
3000	5930	820	8039	207
3200	6325	875	8574	220
3400	6720	929	9110	234
3600	7115	984	9645	248
3800	7510	1039	10181	262
4000	7905	1093	10716	276
4200	8300	1148	11251	290
4400	8695	1203	11787	303
4600	9090	1257	12322	317
4800	9485	1312	12858	331
5000	9880	1366	13393	345
5200	10276	1421	13930	358
5400	10672	1476	14467	372
5600	11068	1531	15004	386
5800	11464	1585	15541	400
6000	11860	1640	16077	414
6200	12254	1695	16612	427
6400	12648	1749	17146	441
6600	13042	1804	17680	455
6800	13436	1858	18214	468
7000	13830	1913	18748	482
7200	14226	1967	19285	496
7400	14622	2022	19822	510
7600	15018	2077	20358	524
7800	15414	2132	20895	538
8000	15810	2187	21432	552
8200	16205	2241	21968	565
8400	16600	2296	22503	579
8600	16995	2350	23038	593

PRESSURE IN PSI	FT.LBS.	TORQUE IN KGM	NM	PRESSURE IN BAR
8800	17390	2405	23574	607
9000	17785	2460	24109	620
9200	18180	2514	24645	634
9400	18575	2569	25180	648
9600	18970	2624	25716	662
9800	19365	2678	26251	676
10000	19760	2733	26787	690

* ISO DOCUMENT 9000REV. 05/1998

IMPORTANT SAFETY INSTRUCTIONS

WARNING: Your **HYTORC TORQUE MACHINE** is a power tool, and as with any power tool, certain safety precautions should be observed to avoid accidents or personal injury. The following tips will assist you.

- **READ ALL INSTRUCTIONS.**
 - **KEEP WORK AREA CLEAN AND WELL LIT.**
 - **CONSIDER WORK AREA ENVIRONMENT.** Electrical Pumps should never be used in an atmosphere which can be considered potentially volatile. If there is any doubt, use an air pump. Also Note: metal to metal contact can cause sparks, precautions should be taken.
 - **AVOID PREMATURE TOOL STARTING.** The Pump Remote Control is for the **TOOL OPERATOR** only.
 - **STAY CLEAR DURING OPERATION.** In most cases, the tool will allow “hands free” operation. If the tool must be held or steadied during operation, use alternative means of securing the tool to the application
 - **GUARD AGAINST ELECTRIC SHOCK.** Ensure the pump is properly grounded and the proper voltage is being used
 - **STORE IDLE TOOLS.** When not in use, tool and accessories should be properly stored to avoid deterioration
 - **USE RIGHT TOOL.** Don't force small tools or attachments to do the job of a larger tool. Don't use a tool for purposes not intended.
 - **PROPER SAFETY ATTIRE.** When handling/operating hydraulic equipment use work gloves, hard hats, safety shoes and other applicable clothing.
 - **USE SAFETY GLASSES.**
 - **MOVING EQUIPMENT.** Do not use hydraulic hoses, uni-swivels, pump power or remote cords as means of moving the equipment.
 - **MAINTAIN TOOLS WITH CARE.** For top performance, inspect tools, powerpack and accessories for visual damage frequently and always prior to use. Always follow instruction for proper tool and pump maintenance. Refer to the Operations Maintenance Section for further clarification
 - **STAY ALERT.** Watch what you are doing. Use Common sense. Do not use power equipment under the influence of any mood altering substances.
 - **PRIOR TO OPERATION**
 - Ensure that all hydraulic connections are securely connected and there is no leakage
 - Verify that the Hydraulic hoses are not kinked or otherwise damaged.
 - Ensure the square drive and its retainer are fully and securely engaged.
 - Be certain that all connectors, elbows, fitting and swivels are not bent, loose or damaged.
 - **PRIOR TO USE.**
 - Check sockets for size, quality and flaws. (Do not use if questionable)
 - Cycle tool to ensure proper function.
 - Locate a solid, secure reaction point.
 - Be sure the reaction arm retaining clamp is fully engaged.
 - Be sure the hydraulic hoses are free of the reaction point.
 - Pressurize the system momentarily; if the tool tends to “ride up” or to “creep”, stop and re-adjust the reaction arm to a more solid and secure position.
- NOTE:** Remain clear of the reaction arm during operation and never put body parts between reaction arm and reaction surfaces.
- **ALWAYS USE QUALITY ACCESSORIES.** Always use top quality impact sockets in good condition which are the correct size and fully engage the nut. Hidden flaws, however, remain a possibility which could cause breakage, so stay clear of sockets during operation
 - **DO NOT USE** other equipment to enhance performance (Hammer on Socket/Tool)**NOTE:** Hytorc Pumps are designed to operate Hytorc Tools only. Damage may occur to the pump or the product that is being operated due to misuse.

SAVE THESE INSTRUCTIONS FOR FUTURE USE!